

## General Maintenance

1. Often check the fasteners and tighten if needed. The fasteners should not loosen regularly; if they do, there is an installation problem that should be resolved.
2. Clean the product regularly by following the cleaning instructions listed below.

**Note:** Try the recommended procedure on small area prior to treating the entire product to verify it works on your particular application and if you are satisfied with the results. Routine cleaning extends the life of all finishes.

Finish Code	Finish	Cleaning Instructions
US3	Polished & lacquered brass	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US3UL	Polished unlacquered brass	Use a soft cloth and a good metal cleaner. We recommend Noxon 7 Metal Polish by Reckitt Benckiser.
US4	Satin finish & lacquered brass	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US9	Polished & lacquered bronze	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US10	Satin finished & lacquered bronze	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US10B	Satin Oxidized & oiled bronze	Use a soft cloth and a paste furniture wax. Buff lightly so as not to remove the dark oxide coating where it remains.
US10BL	Satin Oxidized, lacquered bronze	Use a soft cloth and mild soap and water. Never use brass polish or an abrasive cleaner unless you intend to remove all lacquer and totally refinish the product.
US14	Bright Nickel plated	Use a soft cloth and a good metal cleaner. We recommend Noxon 7 Metal Polish by Reckitt Benckiser.
US15	Satin Nickel plated	Use a soft cloth and a good metal cleaner. We recommend Noxon 7 Metal Polish by Reckitt Benckiser.
US26	Polished chrome plated	Use a soft cloth and a good metal cleaner. We recommend Noxon 7 Metal Polish by Reckitt Benckiser.
US26D	Satin chrome plated	Use a soft cloth and a good metal cleaner. We recommend Noxon 7 Metal Polish by Reckitt Benckiser.
US28	Anodized aluminum	Use a soft cloth and mild soap and water.
	Bronze or black anodized aluminum	Use a soft cloth and mild soap and water.
US32	Polished stainless steel	Use a soft cloth and a good metal cleaner. We recommend Noxon 7 Metal Polish by Reckitt Benckiser.
US32D	Satin stainless steel	Use a soft cloth and a good metal cleaner. We recommend Noxon 7 Metal Polish by Reckitt Benckiser.
	Powder Coat finishes	Use a soft cloth and mild soap and water.